



Gummi / rubber
optional

DE Montage

Ein Ende des Spannbands von unten durch das Spannstück führen und umbiegen. Spannband um den Lenker/ Vorbauschaft legen, durch den zweiten Schlitz des Spannstücks führen, leicht straff ziehen und ebenfalls umbiegen. Beide Enden sollen ca. 1 bis 2 cm überstehen - falls nötig kürzen.

Runden Sockel und Scheinwerferhalter aufsetzen, ausrichten und mit zuvor an Kopf und Gewinde gefetteter Schraube spannen und kräftig festziehen.

Bei Carbonlenkern Gummiunterlage zur Schonung unter das Edelstahlband legen und Band nur mäßig fest spannen.

EN Mounting

Push one end of the tightening strap from below through the tension plate and bend it. Place tension strap around the handle bar/ stem, take it through the other slot of the plate, pull slightly tight and bend it over likewise. Both ends overlap approx. 1 to 2 cm on each side – trim them if necessary.

Mount and adjust round base and bracket with the screw -grease head and thread in advance and tighten firmly.

On carbon handle bars use a rubber pad for protection below the stainless steel band and clamp the strap not too tight.